

Part No.	No.pairs x cross-sec. mm ²	Outer ø ca. mm	Cop. weight kg / km	Weight ca. kg / km	AWG-No.
19034	1 x 2 x 0,25	3,3	5,0	32,0	24
19035	2 x 2 x 0,25	5,5	10,0	37,0	24
19036	3 x 2 x 0,25	5,8	15,0	47,0	24
19037	4 x 2 x 0,25	6,5	20,0	58,0	24
19038	5 x 2 x 0,25	7,2	25,0	70,0	24
19039	6 x 2 x 0,25	8,0	30,0	80,0	24
19040	7 x 2 x 0,25	8,0	35,0	89,0	24
19041	8 x 2 x 0,25	8,8	40,0	99,0	24
19042	10 x 2 x 0,25	10,3	50,0	114,0	24
19043	11 x 2 x 0,25	10,5	55,0	126,0	24
19044	12 x 2 x 0,25	10,5	60,0	137,0	24
19045	14 x 2 x 0,25	11,3	70,0	161,0	24
19046	15 x 2 x 0,25	11,7	75,0	174,0	24
19047	16 x 2 x 0,25	12,1	80,0	187,0	24
19048	18 x 2 x 0,25	12,8	90,0	212,0	24
19049	20 x 2 x 0,25	13,6	100,0	234,0	24
19050	22 x 2 x 0,25	14,4	110,0	250,0	24
19051	24 x 2 x 0,25	14,4	120,0	280,0	24
19052	25 x 2 x 0,25	14,8	125,0	300,0	24
19053	26 x 2 x 0,25	14,8	130,0	320,0	24
19054	27 x 2 x 0,25	14,8	135,0	330,0	24
19055	28 x 2 x 0,25	16,1	140,0	345,0	24
19056	30 x 2 x 0,25	16,1	150,0	370,0	24

Part No.	No.pairs x cross-sec. mm ²	Outer ø ca. mm	Cop. weight kg / km	Weight ca. kg / km	AWG-No.
19057	32 x 2 x 0,25	16,9	160,0	410,0	24
19058	34 x 2 x 0,25	17,5	170,0	425,0	24
19059	36 x 2 x 0,25	17,5	180,0	440,0	24
19060	38 x 2 x 0,25	18,3	190,0	480,0	24
19061	40 x 2 x 0,25	19,0	200,0	530,0	24
19062	44 x 2 x 0,25	20,0	220,0	580,0	24
19063	45 x 2 x 0,25	20,2	225,0	600,0	24
19064	50 x 2 x 0,25	21,0	250,0	650,0	24
19065	52 x 2 x 0,25	21,0	260,0	670,0	24
19066	55 x 2 x 0,25	21,7	275,0	790,0	24
19067	1 x 2 x 0,34	3,6	6,5	36,0	22
19068	2 x 2 x 0,34	6,4	13,1	42,0	22
19069	3 x 2 x 0,34	6,8	19,6	50,0	22
19070	4 x 2 x 0,34	7,3	26,1	61,0	22
19071	1 x 2 x 0,5	3,9	9,6	42,0	20
19072	2 x 2 x 0,5	7,4	19,2	51,0	20
19073	3 x 2 x 0,5	7,4	28,8	62,0	20
19074	4 x 2 x 0,5	8,3	38,4	73,0	20
19075	1 x 2 x 0,75	4,4	14,4	47,0	18
19076	2 x 2 x 0,75	7,8	28,8	59,0	18
19077	3 x 2 x 0,75	8,3	43,2	74,0	18
19078	4 x 2 x 0,75	9,0	57,6	93,0	18

Dimensions and specifications may be changed without prior notice. (RB01)

Our Service on the Internet

The screenshot shows the HELUKABEL website's navigation and service sections. At the top, there are links for 'Download centre' and 'Logistic centre'. Below that is a main navigation menu with items like 'Company', 'Products', 'Quality', 'News', 'Contact', 'Service', 'Opinion', and 'Imprint'. A secondary menu shows 'You are here: Home > Contact > Contact person'. The 'Contact person' section includes a list of links: 'Subsidiaries and Agencies', 'Headquarters Hemmingen', 'Approach', and 'Contact person'. A search bar is visible on the right. Below the navigation, there is a 'Post code search for Germany' section with a text input field and a button labeled 'Finden Sie Ihren Ansprechpartner'. On the right side, there is a 'HELUKABEL world-wide' section featuring a world map and a dropdown menu labeled 'please select...'. The HELUKABEL logo is prominently displayed at the top right of the interface.

Contact person

Enter your postal code to find out your personal customer sales consultant, who serves as your contact for questions and offers. Simply click and check it out. We are looking forward to hearing from you.

www.helukabel.de